

www.cozyproducts.com sales@cozyproducts.com

Chicago, IL 60612

FOOTWARMER

Thermostatically-controlled uniform radiant heat

For use on concrete, stone or tile floors. (Do not use on carpeting or wood floors.)



INSTRUCTIONS:

- 1 Plug in
- 2 Push switch on cord to "ON" position (switch is illuminated when "ON")
- 3 Observe safety precautions:
 - Do not cover
 - Do not fold or twist
 - · Do not use if cut or damaged
 - Do not use if you have impaired sensation in your extremities
 - Keep from pets and children
 - Keep dry and free from obstruction
 - For "indoor use" only



Certificate No.: 72101933 UL 499 (13th edition) Revision March 5, 2008 CAN/CSA C22.2.88-58 + GI1 (R2008)

REORDER: #FW 14" x 21" 90 watts #FWB 16" x 36" 135 watts

GENERAL INFORMATION:

HOW IT WORKS

FOOTWARMER has been pre-tested and set to the correct temperature for use. The mat has been designed so warmth travels upward, circulating around your feet and legs.

TEMPERATURE

FOOTWARMER contains an electric heating element that produces a uniform radiant heat. It is thermostatically controlled so that the heat will be maintained at a constant temperature. The heating element is molded within the rubber to eliminate the danger of fire or electrical shock. (As with any new heated rubber product, the rubber odor may be noticeable when plugged in for the first time. This is temporary, and will dissipate quickly.)

PLACEMENT

For use on concrete, stone or tile floors. Do not use on carpeting or wood floors. Take care as to what type of surface you place the mat on – some delicate surfaces may discolor or crack from even this gentle heat. If you are not sure, place some cardboard under the mat for insulation.

IMPORTANT: PLEASE READ BEFORE USE

This appliance has a polarized plug. To reduce risk of electric shock, this plug is intended to fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

WARRANTY: This product is warrantied against defects in materials and workmanship for a period of six months from the shipping date. At the option of Cozy Products, we will either replace or repair the defective unit.

WARNING: Take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to suitability or fitness of these devices for any specific application. While product includes an overtemperature regulator, misuse may cause failure, damaging the product, mounting surface or work area. Do not drape or cover product with any material. Always allow heat to escape. Protect from puncture. Turn off when not in use.

<u>Use caution as you would with any hot product, especially if you have any issues with loss of feeling in the areas affected by the heat.</u>